



QUICK START GUIDE

WAVE200 TWS



WHAT'S IN THE BOX

HOW TO WEAR

1 TRY DIFFERENT SIZES OF EARTIPS FOR BEST FIT AND SEAL.

S / M / L

2

FIRST TIME USE

1

2

POWER ON & CONNECT

1

2

CHOOSE "JBL WAVE200TWS" TO CONNECT

DUAL CONNECT

L R
STEREO MODE

L/R
MONO MODE

BUTTON COMMAND

1. STEREO MODE

2. MONO MODE

SEAMLESS AUTOMATIC SWITCH

- TAP × 1
- TAP × 2
- TAP × 3
- HOLD (2s)

POWER OFF

MANUAL CONTROLS

CONNECT TO A NEW BLUETOOTH DEVICE

RECONNECT LEFT & RIGHT

FACTORY RESET

CHARGING

CHARGE 15 MIN ⚡ = UP TO 1 HR 🎵

2 HR

LED BEHAVIORS

• (BLUE) 📶 BT CONNECTING	• (OFF) 🔋 LOW
• (BLUE) 📶 BT CONNECTED	☀ (WHITE) 🔋 MID
✖ (BLUE) 📶 BT NOT CONNECTED	○ (WHITE) 🔋 HIGH
✖ (BLUE/WHITE) 🔄 FACTORY RESET	
☀ 🔋 CHARGING (RED → ORANGE → GREEN)	• (RED) 🔋 LOW
• 🔋 FULLY CHARGED	• (ORANGE) 🔋 MID
	• (GREEN) 🔋 HIGH

TECH SPEC

Model:	WAVE200TWS
Driver size:	8 mm/ 0.315" Dynamic Driver
Power supply:	5 V --- 1 A
Weight:	47.5 g/ 0.105 lbs
Headset battery type:	Lithium-ion Battery (48 mAh/ 3.7 V)
Charging case battery type:	Lithium-ion Battery (500 mAh/ 3.7 V)
Charging time:	2 hrs from empty
Music playtime with BT on:	up to 5 hrs
Frequency response:	20 Hz ~ 20 kHz
Impedance:	16 ohm
Sensitivity:	108 dB SPL@1 kHz
Maximum SPL:	93 dB
Microphone sensitivity:	-38 dBV/Pa @ 1 kHz
Bluetooth version:	5.0
Bluetooth profile version:	A2DP V1.3, AVRCP V1.6, HFP V1.7
Bluetooth transmitter frequency range:	2.400 GHz - 2.4835 GHz
Bluetooth transmitter power:	12 dBm
Bluetooth transmitter modulation:	GFSK, π/4 QPSK, 8DPSK
Maximum operation temperature:	45°C

